

# Grand Mesa 2,3,4-Pitching Instructions




Grand Mesa 3 pictured


In order to familiarize yourself with your new tent, we recommend you "test pitch" before your first camping trip. For additional information please visit <http://www.kelty.com/c-tents-shelters.aspx>.



Package Includes: Tent Body, Rain Fly, 2 poles, Guy Cords, Tent Stakes, Gear Loft, Pole Bag, Stake Bag.



Step 1: Find an even piece of ground; be sure area is clear of debris. Assemble poles. Lay poles on tent forming an "X".



Step 2: Insert pole tips into grommets on one end of each pole. From opposite corner, flex pole and insert tip into grommet.



Grommet Pole Attachment



Center Pole Clips



Tent Fly Side Release Buckle Attachment



Step 3: Attach center clips to poles at center "X". Work around the tent attaching all clips to the poles.



Step 4: Drape rain fly over tent body. Attach rain fly side release buckles at stake loops. Stake out tent vestibule and guy out as needed.