


Get to Know Your Gear




Getting Started

1. Be sure to **ACTIVATE YOUR WARRANTY** at www.GOALZERO.com/warranty
2. Plug into any USB power source.
3. Position the neck to direct light where needed.

How to Use Your Gear

- 1 **USB plug**
Turns on automatically when plugged into a USB power source.



Technical specs

Usage	
Plugs into any USB port and adjusts for reading light at any angle. Works particularly well with GOAL ZERO GUIDE 10 battery pack.	
Input	
Power port	USB plug, 5V, 150mA (0.75W)
Output	
Light	10 white LEDs, 0.75W total
General	
Weight	1.4 oz (40 g)
Dimensions	17x.25x0.25 in (6x10x2 cm)
Warranty	12 months
Certifications	FCC and CE
Operating temp.	0-120°F (-17-48°C)

Frequently Asked Questions

What is an LED?

LED stands for Light-Emitting Diode. It is a semiconductor light source with high output and low energy draw.

How long will LEDs last?

They are rated for 20,000 hours of use.

Can I replace the LEDs?

No, this is not necessary.

Compatible With

Any USB power source, like:
Laptops

GOAL ZERO products:
GUIDE 10 PLUS battery pack
SHERPA power packs
ESCAPE 150 power pack



USER GUIDE

LED LIGHT
LUNA™

- Fill out your warranty
- Watch demo video
- Download this manual



CONTACT US:

Toll Free: 888.794.6250
675 West 14600 South
Bluffdale, UT, 84065

WWW.GOALZERO.COM

We proudly support Tifie Humanitarian
WWW.TIFIE.ORG