



FIGURE 1




FIGURE 2




FIGURE 3




FIGURE 3a



Detail of center hub ring from the outside of the blind.

Pulling on the center hub cord will expand blind top and walls.


BLIND SET UP INSTRUCTIONS

Blind Luck™ Model No. 65103

WARNING: Read all instructions and safety warnings and follow them thoroughly. Failure to follow these instructions may result in serious injury or death!

- STEP 1: Remove your blind from the carry bag and unclip the tie strap. (fig. 1)
- STEP 2: Spread the corners of the blind out (fig. 2) and flip it open so you see the center hub on the top of the blind.
- STEP 3: Firmly pull the cord attached to the center hub until the top pops out. (fig. 3)
- STEP 4: Lift the top of the blind so you have access to the center hub on one of the walls and firmly pull the hub until the wall pops out. (fig. 3 & 3a)
- STEP 5: Continue around the blind, pulling the hubs one at a time until all of the walls are set up. Your blind should now be standing square.
- STEP 6: Use stakes to secure your blind to the ground. (fig. 4)
- STEP 7: Adjust the windows to your liking. Add native brush to your blind to optimize your camouflage. (fig. 4)

FIGURE 4



Model: Blind Luck™
Shown using Brush Deception™ loops for added concealment.

For Replacement Parts Visit us online at: www.primos.com

BLIND FOLD DOWN INSTRUCTIONS

WARNING: Read all instructions and safety warnings and follow them thoroughly. Failure to follow these instructions may result in serious injury or death!

STEP 1: Remove any native brush prior to folding down or damage may occur.

STEP 2: From the outside of your blind, zip all the windows shut, but leave the door unzipped.

STEP 3: Remove all stakes from the ground and store them in the built-in pouch located inside the zippered door. (fig. 1 & 1a)

STEP 4: With your hand, push on the hub in the center of one of the walls until the tension releases. (fig. 2 & 2a)

STEP 5: Repeat step 4 on the remaining walls; the blind will begin to collapse on itself.

STEP 6: Now that all the walls are collapsed, with your hand, push on the center hub of the roof until the tension gives.

STEP 7: Fold the corners all to one side; you can now see the hubs all together along with the reverse side of the fabric. (fig. 3)

STEP 8: Gather the corners of the blind together and secure with the strap that is attached to the blind. Pull the strap snug. (fig. 4)

STEP 9: Place the blind in the carry bag with the hub end going into the bag first.

STEP 10: Store in a cool, dry place.

Some models come with "shoot-through" screens. Replacement screens are available, please visit us at www.primos.com for more information.

FIGURE 1




FIGURE 1a




FIGURE 2




FIGURE 2a

Detail of center hub ring from the outside of the blind.

Pushing on the center hub ring will collapse blind walls and top.




FIGURE 3





FIGURE 4



WARNING: This product is not fireproof. The fabric will burn if it comes into contact with an open flame or fuel source. Keep product away from direct flame. Failure to follow this warning may result in serious injury or death!

WARNING: This product is for hunting purposes only! It is not to be used as a camping tent or for any other function. Failure to follow this warning may result in serious injury or death!

WARNING: Do not use devices that produce fumes inside of blind. Vapors and fumes could result in carbon monoxide poisoning, serious injury, or death!

WARNING: Do not allow children or adults to use lighted candles, matches, or other sources of fire near this product. Failure to follow this warning may result in serious injury or death!

WARNING: Do not allow the material to cover your face. This may result in serious injury, suffocation, and death!

WARNING: Do not allow children to use this product without direct adult supervision. Failure to follow this warning may result in serious injury or death!

TIPS FOR INCREASING PRODUCT LONGEVITY

Always store your blind in a cool dry place and make sure that your blind is completely dry and clean before storing in carrying bag.

Never leave your blind outside for any longer than needed. This material may fade after long periods of time in direct sunlight. Pooling of rain or snow may cause permanent damage to your blind.

For Replacement Parts Visit us online at: www.primos.com