


Meramac Instruction Sheet

Pitching your tent for the first time: we recommend that you practice pitching your tent before you actually leave for your first trip.


1. Choose a suitable pitching site by removing all sharp objects which may damage the floor. Spread out the tent on the ground, making sure the door zippers are closed but the window zippers are at least partially open which lets air into the tent as you're setting it up.

2. Assemble the 3 pole sets, making sure all the pole sections slide completely together.


The shorter pole set is for the fly.




3. Lay the 2 assembled tent pole sets on top of the tent. Start by placing the ends of the poles onto the pins at the tent corners until all 4 are in place and the poles form a dome over the tent.



4. Attach the clips for the tent around the poles to assemble the tent.



5. Place the remaining pole set into the pole pockets located at each flysheet end. Lay the flysheet over the tent. Attach the s-hook from each corner of the flysheet to the ring at each corner of the tent. Place a tent peg at each tent corner.



6. If the conditions are windy, or if you anticipate that it may become windy, it is advisable to attach the guy lines as shown in the sketch below. The most important guy lines are the ones on the side of the tent where the wind is blowing. Proper guying on the side of the wind will keep the tent from shifting around.

