



## EXPLODED VIEW & PARTS LIST

# MODEL C31 BB Repeater CO<sub>2</sub> Air Pistol



Manufacture Start Date: 04/22/08

Last Update / /1

CROSMAN CORPORATION  
7629 ROUTES 5 & 20  
BLOOMFIELD, NY 14469  
Phone: 1-800-724-7486  
Parts Order Fax: 585-657-5405  
[www.crosman.com](http://www.crosman.com)

- This EVP and parts list is intended to be an informational guide in ordering parts. It is not instructional material and we therefore assume no responsibility for those who use the same without proper factory training.
- Please order by part number and description.
- Check or money order for the total price must accompany the order.
- For current prices contact Crosman Corporation at 1-800-724-7486 or visit our website [www.crosman.com](http://www.crosman.com)

## C31 PARTS LIST

**ONLY THE HIGHLIGHTED PARTS BELOW ARE AVAILABLE TO PURCHASE**

PART #	DESCRIPTION	QTY	PART #	DESCRIPTION	QTY
C31-1-01	FRAME - Left	1	<b>C11-005</b>	<b>CLIP (magazine) ASSY</b>	
C31-1-02	FRAME - Right	1		<b>- (C21/C31)</b>	<b>1</b>
C31-1-03	HAMMER CATCH	1	5-01	MAGAZINE BODY	1
C31-1-05	GRIP	1	5-02	MAGAZINE COVER	1
<b>C31-1-06</b>	<b>MAGAZINE CATCH</b>	<b>1</b>	5-03	BB FOLLOWER	1
C31-1-07	TRIGGER	1	5-04	BB GUIDE	1
1-08	SAFETY	1	5-06	MAGAZINE SPRING	1
1-09	SAFETY PARTS	1	5-07	BB GUIDE SPRING	1
1-10	SAFETY SPRING SEAT	1	<b>C31-7</b>	<b>VALVE ASSY</b>	<b>1</b>
1-11	RECOIL SPRING STOPPER	1	7-01	VALVE RING	1
1-12	FIXING GUIDE	1	<b>C31-7-02</b>	<b>VALVE SEAL</b>	<b>1</b>
1-13	BB HOUSING	1	<b>C31-7-03</b>	<b>PIERCER SEAL</b>	<b>1</b>
1-14	AXIS	3	<b>C31-7-04</b>	<b>VALVE CHAMBER</b>	<b>1</b>
1-15	SPRING BAR	1	7-05	VALVE COVER	1
1-16	SCREW	7	7-06	VALVE SPRING	1
1-18	SCREW	1	7-07	VALVE	1
1-19	RECOIL SPRING	1	7-08	COPPER RING	1
1-20	BB STOPPER SPRING	1	7-09	FILTER	1
1-21	FIXING GUIDE SPRING	1	7-10	PIERCER	1
1-22	TRIGGER SPRING	1	7-11	FIXING RING	1
1-23	SAFETY SPRING	2	8A	KNOB COMBINATION	1
1-24	HAMMER CATCH SPRING	1			
1-25	ATTACKED BLOCK	1			
1-26	BB STOPPER	1			
8-02	CO2 CARTRIDGE HOUSE	1			
C31-2	SLIDE COMBINATION	1			
C31-2-01	SLIDE	1			
C31-2-02	FRONT SIGHT SEAT	1			
C31-2-03	FRONT FIBER OPTIC	1			
2-04	SCREW	1			
C31-2-06	FIBER OPTIC SEAT	1			
<b>C31-2-08</b>	<b>U TYPE FIBER OPTIC</b>	<b>1</b>			
3-01	BARREL SEAT – Left	1			
3-02	BARREL SEAT – Right	1			
3-03	EJECTOR – Left	1			
3-04	EJECTOR – Right	1			
3-05	EJECTOR SPRING	1			
3-06	INTERNAL BARREL	1			
3-08	SCREW	1			
3-09	C WASHER	1			
3-10	SCREW	2			

# C31

